


Mod10 is designed to be mounted on systems with dual control rods.

This means that there are rods to connect the spool movement of the valve to handles on the other side of the truck.

Special brackets must be screwed on these control rods, in order to allow to MOD10 modules to push and pull the rods, as the command was caused by the levers.



MOD10 pushes/pulls the brackets and causes the movement of the spool through the dual control rods.

