

RFID-Key Manager

08/2024

The RFID-Key Manager is mainly used for programming the radio key for the PocketEvo, Nano-media or HyPro+ transmitters.

When starting the programme, the appropriate Com Port must be selected to establish a connection to the RFID programming adapter. The appropriate transmitter can be selected in the "Select Transmitter" area. The displays and setting options can change depending on the selection.

The "View" button can be used to switch between the different views. The "RFID - Parameters" (PocketEvo, Nano-media, HyPro+) and "Mapping+Telegram (database 3)" and "Mapping+Telegram (database 4)" windows are of interest here. The views for telegram mapping are only available for PocketEvo.

